

For models that start with BBT, BT, BDV, DV, HSK, ST and C
(BIG CAPTO)

(Example) BBT30 - **32-L150** Index with this model, excluding BBT,
BT, BDV, DV, HSK, ST and C.

Number	Product Name	Listed Page
20/32/50-L	DYNA TEST..... HSK	I14
211-	Center Bolt (For AUTOMATIC BACK SPOT FACER)	J49
215-	Lock Screw (For AUTOMATIC BACK SPOT FACER)	J49
27-□-CS	Spindle (For AUTOMATIC BACK SPOT FACER)	J44
32/40-L	DYNA TEST..... BIG CAPTO	I14
32/50-L	DYNA TEST..... BBT	I13
	NT	I13
34-□□□	Wing (For AUTOMATIC BACK SPOT FACER).....	J48
34-□□□-□□	Wing by Angle (For AUTOMATIC BACK SPOT FACER)	J50
35-□□□	Wing by Angle (For AUTOMATIC BACK SPOT FACER)	J50
37-□□□	Wing (For AUTOMATIC BACK SPOT FACER).....	J44
3DM-10N	3D MASTER RED	I5
□-6	Clamp Screw (For AUTOMATIC BACK SPOT FACER)	J49
40/50-Z	DYNA TEST..... BBT	I15
40/50-Z□AB	DYNA TEST..... HSK	I15
50-L	DYNA TEST..... BDV	I13
694.	Insert Clamping Screw Set (CK).....	A99

A

AC □-	STRAIGHT COLLET	G28
AC □-F	FACE MILL ARBOR	G29
AC □CS	COLLET STOPPER.....	G28
ACCU-C □	ACCU CENTER.....	I5
AG35-	Adapter for ANGLE HEAD	A164·B24
AG45/NBS □-	ANGLE HEAD AG45/NBS..... BBT	A166
	HSK	C47
AG90-	ANGLE HEAD AG90/NBS..... BBT	A154
AG90-	ANGLE HEAD AG90/COMPACT	BBT
	HSK	C41
AG90-	ANGLE HEAD AG90/BBT30 LIGHTWEIGHT	BBT
AG90-CA □SGM	ANGLE HEAD AG90/Small Bore Type (Head) ..	BBT
	HSK	C50
AG90-CA □SGM-	ANGLE HEAD AG90/Small Bore Type... BBT	A169
	HSK	C50
AG90-FMA □-	ANGLE HEAD AG90/FACE MILLING..... BBT	A161
	BDV	B22
	HSK	C45
AG90-FT □-	ANGLE HEAD AG90/TAPPER..... BBT	A165
AG90/AGH □-	ANGLE HEAD AG90/BUILD-UP..... BBT	A163
	BDV	B23
	HSK	C44
AG90/HMC □-	ANGLE HEAD AG90/HMC	BBT
	BDV	B21
	HSK	C43
AG90/NBS □-	ANGLE HEAD AG90/NBS..... BBT	A155
	BDV	B19
	HSK	C38
AG90/NBS □-□LS	ANGLE HEAD AG90/LONG..... BBT	A157
AG90/TC □-	ANGLE HEAD AG90/TAPPER..... BBT	A165
	HSK	C46
AGB □-	ANGLE HEAD AG90/Small Bore Type (Base Unit)...	BBT
	HSK	C50
AGU/NBS □-	ANGLE HEAD Universal Type..... BBT	A167
	BDV	B25
	HSK	C48
AGU30/NBS □-	ANGLE HEAD AGU30	BBT
	HSK	C49

AM-□

AM-M

AML-□

AML-M

AMM-□

AMM-M

AMP-M

ARG

ASA8

ASA8-6

ASP-□

ATB□

ATC□

ATE□

ATS□R

AUTO-B□-

AUTO-B□-□R

AUTO-E□-

AWC□

B

B□

B□-DCLNR

B□-DDUNR

B□-SCLCR

B□-SDUCR

B□-STUPR

B□-SVPBR

BBT50-BBT40-□

BC

BFM□

BFN□

BH

BM-□GH

BM-50H

BM-50MH

BMM-□

BPS□-□

BR□

BRG

BSL

BSLA

BW-CKB□-EWN

BW-M□

BWN200FB

BWN200FB-AL

BWN200PB/-AL

C

C□

C□-

C□-

C□-

ACCU STAND..... I22·I23

ACCU STAND..... I20

ACCU STAND..... I22

ACCU STAND..... I20

ACCU STAND..... I22

ACCU STAND..... I20

ACCU STAND..... I20

Insert (For FULLCUT MILL FCM)..... J18

Dial Gauge Adapter (For ACCU STAND)
Clamp Piece (For ACCU STAND)	I21
ACCU STAND.....	I20·I21·I22·I23
AUTO TAPPER B.....	**For Lathes**.....
ATC ALIGNMENT TOOL	I18
AUTO TAPPER E.....	**For Lathes**.....
SYNCHRONIZED TAP HOLDER R	**For Lathes**.....
AUTO TAPPER B.....	**BBT**
	HSK.....
AUTO TAPPER R.....	**BBT**
AUTO TAPPER E.....	**BBT**
α WIPER CLEANER.....	H5
Insert Holder Clamp Screw

Boring Bar Cartridge (For Boring Bar /Turning Adapter)

Boring Bar Cartridge (For Boring Bar /Turning Adapter)

Boring Bar Cartridge (For Boring Bar /Turning Adapter)

Boring Bar Cartridge (For Boring Bar /Turning Adapter)

Boring Bar Cartridge (For Boring Bar /Turning Adapter)

Boring Bar Cartridge (For Boring Bar /Turning Adapter)

Adapter (FULLCUT MILL).....

Collet with Nut (For BABY CHUCK)

BF-CUTTER

SQUARE TOOL HOLDER for Large Diameter

SQUARE TOOL HOLDER (For Turning)

HSK-T

BIG CAPTO ..

BASE MASTER

BASE MASTER

BASE MASTER

BASE MASTER MINI.....

BABY PERFECT SEAL

Balance Ring Clamp Screw (EWB BORING HEAD).....

Insert (For FULLCUT MILL FCR).....

Side Lock Holder for Boring Bar (For Turning)

HSK-T

BIG CAPTO ..

BSL Sleeve (For BSL SIDE LOCK HOLDER).....

Balance Weight (PIN TURNING).....

Balance Weight (PIN TURNING).....

Balance Weight

(EWN Standard type for Large Diameters)

Aluminum Balance Weight

(EWN HIGH-SPEED Type for Large Diameters)

Simple Balance Weight

(EWN200 BORING HEAD/High-Speed Type for Large Diameters)

C-CUTTER MINI (Single Insert Type) ...

BIG PLUS Basic Holder for BIG CAPTO ...

Straight Collet (For BABY CHUCK)

Straight Collet.....

E

EWN200AL	ALUMINUM EWN BORING HEAD (For High Speed Compatible Large Diameters)A60
-----------------	--

F

F	90° Type F Basic Holder (TURNING TOOL) ... BBT-ME12 HSK-TE18 BIG CAPTOE28
F -DCLN	90° Type F Cartridge (TURNING TOOL)E6
F -DDJN	90° Type F Cartridge (TURNING TOOL)E6
F -DTJN	90° Type F Cartridge (TURNING TOOL)E6
F -SVQB	90° Type F Cartridge (TURNING TOOL)E6
FCM -	FULLCUT MILL FCM BBT J10 BDV J12 HSK J13 BIG CAPTO J15 ST J16
FCR -	FULLCUT MILL FCR BBT J1 BDV J3 HSK J4 ST J5
FK -	Wrench G30
FLN	Flange (For High Speed Compatible Large Diameters) A51 · A52 · A59 · A60
FM -PLS	SPEED FINISHER J23
FM -SFM	SURFACE MILL J25
FMA -	FACE MILL ARBOR TYPE A BBT/BTA121 HSK C30 · C66 BIG CAPTOE56
FMB -	FACE MILL ARBOR TYPE B BBTA123
FMC -	FACE MILL ARBOR TYPE C BBT/BTA124 BIG CAPTOE56
FMH -	FACE MILL ARBOR TYPE H BBTA116 BDVB16 HSK C27 BIG CAPTOE55
FMH -FCM	FULLCUT MILL FCM J21
FONBC -	NEW BABY COOLANT COLLETG9
FS LC	WRENCH (For SUPER KEYLESS CHUCK)A125

G

GRG-02	CK Grease GunA100
GTG -	HIGH SPINDLE BBTA179 BDVB27
GTX -	HIGH SPINDLE BBTA180 BDVB27

H

H	Axial Adjusting Screw (RW HEAD)A101
H	Radial Adjusting Screw (MW HEAD)A101
H	Tool Carrier Clamp Screw (EW15/18 BORING HEAD)A102
H	Toolholder Clamp Screw (EWN INSERT HOLDER)A103
H	Toolholder Clamp Screw (EWE INSERT HOLDER)A103
H	Toolholder Clamp Screw (EWB INSERT HOLDER)A104
H	Lock Screw for SIDE LOCK HOLDER (EWN/EWE/EWB INSERT HOLDER)A102
H	Spare Lock Screw (For CENTER BOY) J42
H /R	Radial Adjusting Screw (RW HEAD)A101
H FS	SIDE LOCK SCREWS (For MOLD CHUCK)A128 · C33
HDA	ADJUSTING SCREW (For HYDRAULIC CHUCK) A30 · C21 · E50

HDC

Hydraulic Chuck (Standard Type) BBTA30 · A74 BDVA74 · B12 HSK A74 · C21 ST D6 BIG CAPTOE50

HDC

HDC

HDC

Hydraulic Chuck (LATHE Type) For LathesF7
Hydraulic Chuck (Rigid Type) BBTA35
Hydraulic Chuck (Jet Through Type) .. BBTA28 BDVB11 HSK C20 BIG CAPTOE49

HDC

HDC

Hydraulic Chuck (Standard Type) BBTA33 · A74 BDVB12
Hydraulic Chuck (SUPER SLIM Type) .. BBTA26 BDVB11 HSK ... C19 · C58 · C65 ST D6 BIG CAPTOE48

HDC

HDC

HMA

HMC

Hydraulic Chuck UP (SUPER SLIM Type) ... HSK C57
Hydraulic Chuck (EXTRA SLIM Type) ... HSK C57
Axial Adjusting Screw G30
NEW HI-POWER MILLING CHUCK ... BBT/BTA23 BIG CAPTOE47
NEW HI-POWER MILLING CHUCK (S Type) .. BBT/BTA20 BDV/DV B9 HSK C16 BIG CAPTOE47

HMC

HMC

HMC12J

RUNOUT ADJUSTABLE RA HOLDER (MILLING CHUCK) BBTA25 HSK C18
NEW HI-POWER MILLING CHUCK (12J Type) .. BBTA22 BDV/DVB10 HSK C17 ST D5

HSG50

HSK

HSK

HSK

HSK

GreaseA100
ACCU STAND HSKI23
HSK Coolant Pipe C67
HSK Coolant Pipe C67
HSK Plug C67

I

ISL

SIDE LOCK ENDMILL HOLDER BBT/BTA129 HSK C31 BIG CAPTOE57

J

JTA

JACOBS TAPER ARBOR BBTA125 BIG CAPTOE57
--

K

K

K

K

K

K

K

K

K

Tool Carrier Clamp Screw (EWB BORING HEAD)A104
Tool Carrier Clamp Screw (EWE BORING HEAD)A103
Tool Carrier Clamp Screw (EWN BORING HEAD) A102 · A104
Clamping Screw (SIDE LOCK ENDMILL HOLDER PIN Type) ... BBT/BTA130
KOMBI GRIP H4
SUPER KEYLESS CHUCK BBTA125

L

LM

LM

LSN35

LVM-01

LATHE MASTERI10
Collar SetI10
Lifting Screw Set J23
LEVEL MASTERI19

M

M□-	CK CYLINDRICAL TOOLHOLDER	A67·A68·A69
M□-	SCREW-ON HOLDER	BBT A132
		BDV B18
		HSK C34
M□T6	INSERT HOLDER CLAMP SCREW (EW15/18 BORING HEAD)	A102
M1010-25	EXTENSION (PIN TURNING)	A75
MB20-	BABY CHUCK	ST D4
MBA-M□	CLAMPING SCREW (For FACE MILL ARBOR)	A121·C30·E55
MEC□-□	MEGA E Collet	G18
MEGA□D-	MEGA DOUBLE POWER CHUCK (Standard Type)	BBT A15
		HSK C12·C63
MEGA□DPG	MEGA PERFECT GRIP	BBT A19
		DV B8
		HSK C15
MEGA□DS-	MEGA DOUBLE POWER CHUCK (Jet Through Type)	BBT A17
		BDV B7
		HSK C14·C64
		BIG CAPTO E46
MEGA□E-	MEGA E CHUCK	BBT A7
		BDV B4
		HSK C7·C62
		BIG CAPTO E43
MEGA□E-□/NL	MEGA E CHUCK/WITHOUT NUTS ...	BBT A7
		HSK C8
MEGA□N-	MEGA NEW BABY CHUCK	BBT A3
		BDV/DV B2
		HSK C3·C55·C61
		BIG CAPTO E40
MEGA□N-□/NL	MEGA NEW BABY CHUCK/WITHOUT NUTS ...	BBT A3
		HSK C4
MEGA□S	MEGA MICRO CHUCK (Straight Type) ..	BBT A2
		BDV B1
		HSK C2·C54·C60
		ST D1
		BIG CAPTO E39
		For Lathes F1
MEGA□S-□T	MEGA MICRO CHUCK (High-Rigidity Taper Type)	BBT A1
		BDV/DV B1
		HSK C1·C53·C59
		BIG CAPTO E39
MEGAER□	MEGA ER GRIP	For Lathes F5
MEN	MEGA E NUT	G18
MER□SN	MEGA ER SOLID NUT	G21
MERN□	MEGA ER NUT	G21
MERPS□	MEGA ER PERFECT SEAL	G22
MES-□	Merit Set	A175
MGN	MEGA NUT (For MEGA NEW BABY CHUCK) ..	G12
MGN□F	MEGA NUT Flat Type (For MEGA NEW BABY CHUCK) ..	G12
MGN□S	MEGA NUT (For MEGA MICRO CHUCK)	G6
MGN□S-PS	MEGA MICRO SEAL NUT	G6
MGN□T	MGT Nut (MEGA SYNCHRO TAPPING)	G31
MGN□S-□J	MEGA MICRO COOLANT NUT	G6
MGR-TL/P	Digital MEGA TORQUE WRENCH	G35
MGR□/L	MEGA Wrench	G33
MGR□A-N	Adapter (Digital MEGA TORQUE WRENCH) ..	G35
MGR□TL	MEGA Torque Wrench	G34
MGR□TTL	MEGA Torque Wrench (For MEGA SYNCHRO TAPPING) ..	G34

MGT□-

MGT□-□-

MGT□-M/U/P□-

MGT□OR

MGT□SA□

MGT□SS

MGT3-

MGT36-

MGT36□

MPS□-□

MTA□-

MW□

MW□E

MW0404

MW□BS

MW□SS

N

NBA□-M

NBA□B

NBB

NBB□S

NBC□-□

NBC□-□E

NBC□-CE

NBC□-M□

NBC□E-CE

NBC□S-□

NBJ

NBK□

NBK□TL/TLs

NBN

NBS□-□

NBS□-□/NL

NBS□-□NRA

NBS□CH

MEGA SYNCHRO TAPPING HOLDER ... **BBT** A133**BDV/DV** B14**HSK** C35**ST** D11**BIG CAPTO** E54For Tap Holder DIN/ISO (For MEGA SYNCHRO TAPPING) A136 |

For Tap Holder JIS (For MEGA SYNCHRO TAPPING) A134 |

O Ring Set (For MEGA SYNCHRO TAPPING) G31 |

Synchro Adjuster (For MEGA SYNCHRO TAPPING) G31 |

MGT Set Screw (For MEGA SYNCHRO TAPPING) G31 |

MEGA SYNCHRO TAPPING HOLDER/
For Small Diameters **BBT** A138 |

HSK C36

ST D11

For Lathes F13

MEGA SYNCHRO TAPPING HOLDER/
For Large Diameters **BBT** A139 |

BDV/DV B15

HSK C36

For Large Diameter Tap Holder (JIS) A139 |

(DIN) A139·B15 |

MEGA SYNCHRO TAPPING HOLDER/
Optional Accessories for Large Diameters G32 |

MEGA PERFECT SEAL G13 |

MORSE TAPER HOLDER TYPE A **BBT/BT** A126

HSK C32

BIG CAPTO E58

MW BORING HEAD **ST** A49·D8 |

Cartridge (For MW HEAD) A49·D8 |

Insert (For MW HEAD) A50·D8 |

Belleville Spring (MW HEAD) A101 |

Clamping Screw (MW HEAD) A101 |

Tap Adjusting Screw G23 |

Adjusting Screw G23 |

Collet Case (For New Baby Collet) G10 |

Collet Case (For Micro Collet) G6 |

NEW BABY COLLET G7 |

NEW BABY ENDMILL COLLET (Endmill Exclusive) G10 |

COLLET EJECTOR G11 |

Tap Collet (For NEW BABY CHUCK) G17 |

COLLET EJECTOR G11 |

Micro Collet G4 |

Collet Remover G11 |

New Baby Wrench G36 |

Torque Wrench (For NEW BABY CHUCK) G36 |

NEW BABY NUT G15 |

NEW BABY CHUCK **BT** A9 |

BBT A10

DV B5

HSK C9

ST D2

BIG CAPTO E45

For Lathes F2

NEW BABY CHUCK/WITHOUT NUTS ... **BT** A10

HSK C10

Runout Adjustable RA HOLDER
(COLLET CHUCK) **BBT** A14 |

HSK C11

CENTERING HOLDER **For Lathes** F4 |

O

OAG90 □-	ANGLE HEAD AG90/Oil Hole Type BBT A160 HSK C42
OCA □□-□	OIL HOLE STRAIGHT COLLET A72·G27
OCKB □ N -	Hi-JET HOLDER/CK SHANK Type BBT A174
OMC □ N -	Hi-JET HOLDER/MILLING CHUCK Type... BBT A174
OMT □-□	MT Sleeve for Oil Hole A175
OMT □ N -	Hi-JET HOLDER/MORSE TAPER Type... BBT A175
ONBS □ N -	Hi-JET HOLDER/NEW BABY CHUCK Type... BBT A171 DV B28
OR-S □	O-ring for STRAIGHT COLLET (EWN/EWE/EWB Cylindrical Tool Type) A102
OSL □-	SL Sleeve A173·B29·C32·E37
OSL □ N -	Hi-JET HOLDER/SIDE LOCK Type BBT A173 DV B29

P

PJC □-	Straight Collet (Jet Through Type) G25
PJC □ OR	O Ring for PJC/PSC G26
PKG □	Key Grip (MEGA PERFECT GRIP) A19·B8·C15
PL □	Insert (For SPEED FINISHER) J23
PLP	PL Presetter J24
PLW -□	PULLSTUD BOLT Wrench G40
PMC -□	POINT MASTER I3
PMG -□	POINT MASTER I4
PMP -□	POINT MASTER PRO I2
PMPC	POINT MASTER PRO I1
PS -□	PS RING for PERFECT SEAL G14·G16·G19·G22·G26
PSC □-	Straight Collet (Oil Hole Type) G26
PSP □	Spring (MEGA PERFECT GRIP) A19·C15

R

RBE	Jig Boring Bit A66
RBX □	AIR TURBINE SPINDLE BBT A176 BDV B26 HSK C51
RC □	R-CUTTER ST J39
RC □ ACP300	Insert (For R-CUTTER) A85·J39
RC □ B	R-CUTTER ST J38
RTM0615	Adapter Lock Screw (For TOOLING MATE) H1
RW □-□ CKB □	RW BORING HEAD A47
RW □ A/E	RW CARTRIDGE A48

S

S □	Tool Carrier Clamp Screw (EWB BORING HEAD) A104
S □	45° Type S Basic Holder (TURNING TOOL) .. BBT-M E11 HSK-T E17 BIG CAPTO E27
S □- DCLNN	45° Type S Cartridge (TURNING TOOL) E5
S □- DDHNN	45° Type S Cartridge (TURNING TOOL) E5
S □- DDJN □	45° Type S Cartridge (TURNING TOOL) E5
S □- DTJN □	45° Type S Cartridge (TURNING TOOL) E5
S □- SVLB □	45° Type S Cartridge (TURNING TOOL) E5
S □- SVQBN	45° Type S Cartridge (TURNING TOOL) E5
S □ S	Insert Clamping Screw Set (CK) A99
S □ S -□ IP	Insert Clamping Screw Set (CK) A99
S □ S-A/B/S	Insert Clamping Screw Set (CK) A99
S □ S-T □	Insert Clamping Screw Set (CK) A99
S1.6S-T6	Insert Clamping Screw Set (MW HEAD) A50·D8
S2DS-TPS □	2D Edge Sensor Set (TPS) I12

SBT□-**ASC****SBT30-DF10****SC-HSK**□**SC-MEC**□**SC-MER**□**SC-NBC**□**SC-NBC**□**S****SC**□**SC**□□**06****SC**□□**07****SC**□□**09****SC**□□**12****SC**□**C**□**SCA**□-**SCE**-□**SCH****SDB**□**DP****SDB**□**DP****SDF**□**SDF**□**FMH**□**DP****SDF**□-**M**□**DP****SDV**□-**ASC****SG40-50****SKL**□-**SL**□-**SL**□**F-HDC**□**SL**□**R-HDC**□**SLN**□-**SLN**□-□**AL****SMB**-**SMGR-TL/P****SNBC****SNT**□-**DF**□**SRC**□-**SRC**□**J**-**SRC**□**S**-**SRC**□**SS**-**SSL**□-**SST**□-**MEGA**□**S**-**ST25R-3DM****ST**□-**M**□-**ST**□-**SL**□**ST**□**W-AJ**□**ST**□**W-CKB**□-FLANGE FACE CLEANER **BBT** A181

DYNA FORCE I17

SPINDLE CLEANER H8

 α TAPER CLEANER (For MEGA E CHUCK) H6 α TAPER CLEANER (For MEGA ER GRIP) H6 α TAPER CLEANER

(For MEGA NEW BABY/NEW BABY CHUCK) H6

 α TAPER CLEANER (For MEGA MICRO CHUCK) H6

SPINDLE CLEANER H8

Insert (CK) A94

Insert (CK) A94

Insert (CK) A94

Insert (CK) A94

Distance Collar for SIDE CUTTER ARBOR A130

SIDE CUTTER ARBOR A **BBT** A130**BIG CAPTO** E58 α TOOLING CLEANER H7

Collet Hook G28

BORING BAR BODY

(Built-in Damper SMART DAMPER) ... **For Lathes** F11SMART DAMPER Turning Adapter ... **BIG CAPTO** E38**HSK-T** E22

FMH basic holder

(For Built-in Damper SMART DAMPER) ... **BBT** A119**BDV** B17**HSK** C29

FMH Damper Head

(Built-in Damper SMART DAMPER) A120·B18·C29

SCREW ON HOLDER Damper Head A131

FLANGE FACE CLEANER B29

Setting Gauge (TOOL PRESETTER) I12

SUPER KEYLESS CHUCK **BBT** A125**HSK** C31SIDE LOCK ENDMILL HOLDER **BBT/BT** A130

HYDRAULIC CHUCK

(Back-side Clamping Type) **For Lathes** F8HYDRAULIC CHUCK (Rear-post Type) ... **For Lathes** F9

CK Slide (For Large Diameters) A51·A59

CK Aluminum Slide

(For High Speed Compatible Large Diameters) A52·A60

BABY CHUCK Set D4

Digital MEGA TORQUE WRENCH Set G35

NEW BABY COLLET Set G10

DYNA FORCE I17

SHRINK CHUCK (Standard Type) **BBT** A38**HSK** C24**BIG CAPTO** E51SHRINK CHUCK (Jet Through Type) ... **BBT** A37SHRINK CHUCK (Slim Type) **BBT** A36**HSK** C23**ST** D7**BIG CAPTO** E51SHRINK CHUCK (Super Slim Type) ... **ST** D7MOLD CHUCK **BBT** A128**HSK** C33MEGA MICRO CHUCK Set **ST** D1

STYLUS (3D MASTER RED) I5

CK CYLINDRICAL TOOLHOLDER A67·A68·A69·A70

SIDE LOCK CYLINDRICAL TOOLHOLDER A68·A69

CK Carbide Cylindrical Tool Holder A70

CK Carbide Cylindrical Shank A73·D10

ST □ W-CS □- 45B	C-CUTTER MICRO..... ST J37
ST □ W-EB □-	CK CARBIDE CYLINDRICAL INSERT HOLDER.....A66
ST □ W-EW □-	EW MICRO HEAD A71 · D9
ST □ W-M □-	CK CARBIDE CYLINDRICAL TOOLHOLDER A67 · A68 · A69 · A70
ST □ W-MW □-	CK Carbide Shank..... ST A50 · D8
ST12B-C0525	C-CUTTER BOY..... ST J43
ST15-50K	STYLUS (POINT MASTER).....I4
ST16-SL □-	CK CYLINDRICAL TOOLHOLDER (PIN TURNING).....A75
ST28/ST38-	STYLUS (POINT MASTER).....I4
ST4W/7W-EB □	Cylindrical Tool For EWN04-7/EWN04-15 HEAD.....A61 · A62
STD52-M □	SYNCHRONIZED TAP HOLDER STD52..... A140
STL40	ST LOCK H4
SVQB □	90° Type F Mono-Block Holder (TURNING TOOL) ... BIG CAPTOE30
SVQBN	45° Type S Mono-Block Holder (TURNING TOOL) ... BIG CAPTOE27
SW □-□ CKB □	SW BORING HEADA41
SW □ A/E/N	SW Cartridge (For SW HEAD).....A45
SW □ BS	Belleville Spring (SW HEAD)A101
SW □ DP	SMART DAMPER SW BORING HEADA43
SW □ RS	Radial Adjusting Screw (SW HEAD).....A101
SW □ SS	Clamping Screw (SW HEAD)A101

T

T52- □ TC D	Tap Holder with Float (For DRILL TAPPER).....A149
TAD □	Turning Adapter HSK-TE22
	BIG CAPTOE38
TC □-□	Tap Collet TC TypeA144
TC □-□ O □	OIL HOLE TAP COLLET TC.....A145
TC □□ 11	Insert (CK)A93
TCA50	TC MATE ADAPTER..... H4
TCE □-□	Tap Collet TCE TypeA147
TCM50	TC MATE..... H4
TF- □	TORQUE FIT H3
TKC □	TK CLEANER..... H5
TM-100N	TOOL MASTER.....I9
TMA □-□	Adapter (For TOOLING MATE/TORQUE FIT).....H1 · H3
TMBA-M □	Clamping Screw with Oil Hole (For FACE MILL ARBOR)A121 · C30
TMS □-□	TOOLING MATE H1
TMS □-□ R	TOOLING MATE (For HSK/BIG CAPTO)..... H1
TMS-HSK-A125	TOOLING MATE (Exclusive for HSK-A125 Shank)..... H1
TMU □-□	TOOLING MATE UNIVERSAL H2
TMUA □-	Adapter (For TOOLING MATE UNIVERSAL)..... H2
TP □□ 07	Insert (CK)A91
TP □□ 08	Insert (CK)A92
TPA □ STP	BT Front Clamp Adapter (TOOL PRESETTER)I12
TPA/C □	BIG CAPTO Front Clamp Adapter (TOOL PRESETTER).....I12
TPA/HSK □	HSK Front Clamp Adapter (TOOL PRESETTER).....I12
TPS- □ E	TOOL PRESETTER TPS (Compact Type)I11
TPS- □ N	TOOL PRESETTER TPSI11
TPS-C □	TOOL PRESETTER TPS (For BIG CAPTO)I11
TPS-HSK □	TOOL PRESETTER TPS (For HSK)I11
TPS-HSK □ E	TOOL PRESETTER TPS (Compact Type For HSK).....I11
TS □- S	T-SLOT CLEAN H9
TSB □	Grip Bar (For HYDRAULIC CHUCK) G30
TSL □-	SIDE LOCK DRILL HOLDER BBT/BTA127
	HSK C32
	BIG CAPTOE37
TTB □-	AUTO TAPPER B TYPE CENTER THROUGH... BTA142
TW □ A/E/EL	Cartridge (Large-Diameter TW BORING HEAD).....A51
TW-1	TOOLING WAGON H11

TW-B	Block Case (TOOLING WAGON)..... H11
TW □ BS	Belleville Spring (Large-Diameter TW HEAD/EWN200 Head)A104
TW200E/EL-SC	E Type Cartridge for Step CuttingA52
TW200RS	Radial Adjusting Screw (Large-Diameter TW HEAD)A104

W

WC □□ 02	Insert (CK)A91
------------------------	----------------------

X

XF1	Air filter regulatorA178
------------	--------------------------------

Z

ZNMU □	Insert (CK)A96
---------------	----------------------